

BETTER

Bacteriostatic • Taste • Odor • Chlorine • Sediment

WATERguard™

FILTRATION

Water Filter Cartridge

Model RV-10KDF-A

For SHURflo Water Filter Housings
RV-10UC-A or RV-10VIH-A



For RV/Marine Applications



Water Washed Coconut Shell & KDF-55D Media Cartridge

- Improves taste and reduces odor, chlorine, cloudy water and sediment when used with SHURflo models RV-10UC-A or RV-10VIH-A
- Utilizes KDF-55D Bacteriostatic Media
- Filter life 11,000 gallons*
- Fits most standard brands


*Based on flow rate of 0.75 GPM at 60 PSI

Coque de noix de coco lavée à l'eau et Cartouche de produit KDF-55D

- Améliore le goût et l'odeur, réduit le chlore, l'eau trouble et le sédiment lorsqu'elle est utilisée avec les modèles SHURflo RV-10UC-A ou RV-10VIH-A
- Utilise des produits bactériostatiques KDF-55D
- Durée de vie du filtre: 41 640 litres*
- Convient à la plupart des marques standard

*Calcul basé sur un débit d'eau de 2,83 l/mn à 60 PSI

SHURflo®



SHURflo, LLC

5900 Katella Ave., Cypress, CA 90630

(800) 854-3218 • (562) 795-5200

www.shurflo.com

©2007 SHURflo, LLC 19-731-00 Rev. A

146837 Rev B JA07

TO INSTALL CARTRIDGE

1. Turn off water supply to filter.
2. Open faucet.
3. Depress pressure release button to relieve pressure in housing.
4. Unscrew housing from cap, discard used cartridge, and insert new one.
5. Make sure O-ring is clean and properly seated in groove. Lubricate with an NSF approved lubricant.
6. Screw the housing onto the cap and hand tighten.
7. Turn on water supply to filter one quarter turn and depress pressure release button.
8. When all air has escaped from the system and filter has filled with water, close faucet or valve nearest filter and fully open water supply. Check for leaks.
9. This carbon cartridge will contain a very small amount of carbon fines (very fine black powder) and a new cartridge should be flushed for 5 minutes to remove all traces of fines from your water system before using the water.

Each time you use water from your filtered water tap for drinking or cooking purposes, it is recommended that you run (flush) the tap for at least 10 seconds prior to using water. This is particularly important if the water tap has not been used daily.

10. When the bad taste and odor return to your filtered water, it is time to change the filter cartridge. However, the cartridge should be changed at least every six months as standard practice.

WARNING:

Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.

For use with potable water only.

Filter must be protected against freezing. Failure to do so may result in cracking of filter and water leakage.

Do not exceed maximum pressure of 125 PSI.